

Assembly Information

#405 Victorian Directionals



To create a fancier, more decorative weathervane, our regular directionals & spacer balls can be replaced with item #405 or 405P *VICTORIAN DIRECTIONALS*. They interlock & are installed on the rod the same way as the regular directionals, but without the spacer balls.

